



# CXone Mpower EXPERT

## System ManagerからLOADERに移動する方法

[https://kb-ja.netapp.com/on-prem/ontap/dm/System\\_Manager/SM-KBs/How\\_to\\_get\\_to\\_the\\_LOADER\\_f...](https://kb-ja.netapp.com/on-prem/ontap/dm/System_Manager/SM-KBs/How_to_get_to_the_LOADER_f...)

Updated: Sun, 18 Jan 2026 04:07:13 GMT

### 環境

- ONTAP 9.8 and later
- System Manager
- AFFシステム
- FASシステム
- ASAシステム
- LOADER

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information contained herein may be used solely in connection with the NetApp products discussed in this document.'

## 概要

- この記事では、System Manager 9.8以降からLOADERプロンプトにアクセスする方法について説明します。
- これは、ストレージティクオーバーが有効になっていない限り、システムに影響を与える可能性のあるプロセスです。
- ティクオーバーが有効な場合、ノードのシャットダウン時にパートナーによるストレージティクオーバーが発生します。
- その他のオプションについては、[LOADERプロンプトへのアクセス方法 解決ガイド](#)を参照してください。