



## SolidFireノードで「authenticationServiceFault」エラーが継続する

https://kb-ja.netapp.com/on-prem/SolidFire/Element OS Kbs/Persistent authenticationServiceFault er...

Updated: Thu, 11 Dec 2025 14:34:29 GMT

## 環境

NetApp Hシリーズストレージノード

## 問題

nであるノードでの永続的な認証エラー認証コンテナの再起動、再起動、または電源の放電を行っても解決されません。

Error Code: authenticationServiceFault

Details: Element Auth container has been not ready for too long on node <#>.
Please contact support if this problem persists

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information contained herein may be used solely in connection with the NetApp products discussed in this document.'