



MetroCluster間の移行時のLIF警告の確認MetroClusters

https://kb-ja.netapp.com/on-prem/ontap/MC/MC-KBs/MetroCluster_Check_LIF_warning_during_migrati...

Updated: Sun, 19 Oct 2025 03:28:57 GMT

環境

- MetroCluster IP
- ONTAP 9
- 移行

問題

- metrocluster check show実行時のLIFに関する警告：

例：

```
clusterA::> metrocluster check show  
Component Result
```

```
-----  
nodes ok  
lifs warning  
config-replication ok  
aggregates ok  
clusters ok  
5 entries were displayed.
```

- `metrocluster check lif show` 警告は表示されません